

Avant RT1250 21+

Front Fender Extension

Installation Guide

Fits **2021+ BMW R1250RT**



Care Instructions:

Clean with soap and water.
Armor-All works well to restore appearance.

Tool Required:

Torx T25 Screwdriver

Parts:

2 - Avant Brackets
2 - 8mm T25 Torx Screws
Avant Extension

* PLACE THE BIKE ON ITS CENTER STAND ON LEVEL GROUND.

Turn the handlebars for installation convenience.
Clean the top side of your front fender.

- 1 Avant features two threaded mounting brackets to assure tight assembly.
- 2 Slip the Avant over the front fender until the tip of the fender fits snugly into the receiving shoe. Make sure the sides fit up against the fender's side edges.



- 3 Position a bracket behind the mounting flange in-between the raised ribs. The **bracket tooth faces against the inside of the fender**.
- 4 Pre-tighten the screw with a T-25 Torx driver. Install the opposite side bracket in the same way. Check final alignment and **tighten both screws securely**.

Re-check screw tightness after the first ride and periodically thereafter.



WARNING AND DISCLAIMER: All parts manufactured, designed or sold by Machineart Moto ("MaMo") should be installed by a qualified motorcycle technician. The risk of injury is increased by improper installation or misuse of equipment. MaMo's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by MaMo, the responsibility of MaMo is limited to a refund of the purchase price or the replacement of the part if MaMo determines the part to be defective, and subject to MaMo's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to MaMo products will void this limited warranty). MaMo, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever except as provided by law. MaMo makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.

Copyright 2021 Machineart Inc. All Rights Reserved.

Specialized Products for **BMW** twins

908. 652. 6779 | www.machineartmoto.com

machineart*moto*